

Baptistry Window Installation

For best results, window should be installed after the baptistry has been properly installed.



1. All windows are pre-cut for a loose fit. Before removing protective paper, place window in channel to ensure proper fit.



2. Place a 1/4" bead of adhesive inside the window channel.

3. Remove protective film from both sides of window.



4. Gently place window in channel. Gently seat the window in the adhesive bed.



5. Use remaining adhesive to fill in gaps on the inside and outside of window channel.



6. Use a putty knife to smooth adhesive.

Adhesive must dry for 7 Days before use.